



Motorcycle Brake Fluid.....



Types of Brake fluid

There are 3 main types of brake fluids: DOT3 and DOT4 (both absorbing water) and DOT5 (not absorbing water) Most brake fluid that comes in a new car will be rated DOT 3. A few will Use DOT 4, and very few will ever use DOT 5 which is a silicone based product.

When to change brake fluid?



The manufacturer's service manual will tell you how often you should check the level, and how frequently it should be replaced. As a general rule, the brake fluid level should be checked every 100 km or every month or so, and it should be changed around every two years.